

Mounting Instructions TM RipnWud Skis



Measurements =
Ski boot center

- ALL MOUNTAIN**
 161 AMT 73.0
 171 AMT 76.5
 181 AMT 80.5

- FREERIDE CARVE**
 167 FRC 71.5
 177 FRC 77.5
 188 FRC 83.5

- POWDER FAT STICK**
 166 PWF 71.0
 176 PWF 75.5
 186 PWF 83.0

- PRO SERIES**
 195 PWF 85.0
 194 AMT 85.5

Screw depth Maximum
From top surface
9.0 mm

WARNING: Do not use tap for pre-threading
Screw holes.

IMPORTANT: Apply wood glue in drill holes
Before inserting screws.

For best results tighten screws by hand with screw driver

Measurements are calculated from tail to tip =
recommended ski boot center.

*For Freeride
Mount bindings behind recommended **SKI BOOT
CENTER 1,0cm**

www.ripnwud.com



© KC Enterprise